

VOX AMPLIFIER PARTS LIST

V-1-23

VOX AC50 AMPLIFIER PARTS LIST

MISCELLANEOUS COMPONENTS (Electronic)

Part No.	Description
09-5008-0	9 Pin Tube Socket
09-5012-0	ECC 83/12AX7 Tube
09-5016-0	8' Three Wire Power Line Cord & Plug
09-5017-0	Three Wire Line Cord Plug (Only)
09-5018-0	3 to 2 Lead Plug Adaptor
09-5104-0	Line Voltage Selector Switch
09-5109-0	Phone Jack - Black Cap
09-5110-0	Pilot Light
09-5111-0	On/Off Switch - D. P. S. T.
09-5113-0	Pilot Light Socket & Jewel
09-5114-0	Speaker Lead Junction Block
09-5206-0	ECC 82/12AU7 Tube
09-5304-0	Fuse Holder
09-5306-0	*GZ34 Tube
09-5307-0	3 Amp Fuse
09-5308-0	8 Pin, Tube Socket
09-5401-0	Power Transformer
09-5402-0	Output Transformer
09-5403-0	8 Hy Inductor
09-5404-0	3/4 Amp Fuse ("B" Supply)
09-5405-0	12" Speaker (#122-17)
09-5406-0	Midax Horn (#66850)
09-5407-0	Speaker Cord - 12' (Complete)
09-5408-0	Speaker Cord Socket Only (For Cable)
09-5409-0	Speaker Cord Plug Only (For Cabinet)
09-5410-0	Speaker Impedance Selector Socket
09-5411-0	Speaker Impedance Selector Plug
09-5412-0	Speaker Outlet Cover Plate
09-5413-0	*Neon Bulb
09-5414-0	Silicon Rectifier
09-5415-0	Fuse Holder (Single Clip In Type)

*= Early Production Units

MISCELLANEOUS COMPONENTS (Cabinet)

09-5025-0	Pointer Knob (Black)
09-5035-0	Cup Washer (Back Mounting)
09-5036-0	Wood Screw (Back Mounting)
09-5115-0	Corner Protector (Plastic)
09-5116-0	Cabinet Foot (Plastic)
09-5118-0	Amplifier Cabinet Carrying Handle
09-5123-0	Vox Logo - Plastic
09-5125-0	Metal Screw (Back Mounting)
09-5127-0	Palnut
09-5222-0	Swivel Stand Mtg. Hardware & Chrome Knobs
09-5227-0	Chassis Mtg. Screws (W/Washers)
09-5228-0	Chassis Mtg. Nut (W/Retainers)
09-5231-0	3/8" Grommet
09-5232-0	Tube Shield
09-5426-0	Amplifier Cabinet (Less Hardware)
09-5427-0	Rear Cover Panel (W/Nameplate)
09-5428-0	Wooden Chassis Shelf

MISCELLANEOUS COMPONENTS (Cabinet - Continued)

09-5430-0	Grill Cloth (Amplifier)
09-5431-0	Control Panel (AC50)
09-5432-0	Plastic Mesh Air Vent
09-5435-0	Amplifier Cover (Black)

Speaker Assembly Parts

09-5436-0	Speaker Cover (Black)
09-5437-0	Cabinet (Less Hardware)
09-5438-0	Upper Back
09-5439-0	Lower Back
09-5440-0	1 MFD Capacitor (Crossover)
09-5441-0	Vox Logo (Speaker Cabinet)
09-5442-0	Grill Cloth (Speaker)

CAPACITORS

09-5042-0	25 MFD 25V Electrolytic
09-5046-0	.02 MFD 400V
09-5142-0	16/16 MFD 450V Dual Electrolytic
09-5345-0	500 MMFD 600V
09-5347-0	100 MMFD 600V
09-5348-0	50 MMFD 600V
09-5451-0	32 MFD 500V Electrolytic
09-5452-0	8 MFD 150V Electrolytic
09-5453-0	4 MFD 350V Electrolytic
09-5454-0	.1 MFD 600V
09-5455-0	.05 MFD 1500V

RESISTORS

09-5058-0	1.5 K Ohm $\frac{1}{2}$ W 10%
09-5061-0	22 K Ohm $\frac{1}{2}$ W 10%
09-5062-0	100 K Ohm $\frac{1}{2}$ W 10%
09-5063-0	220 K Ohm $\frac{1}{2}$ W 10%
09-5064-0	1 Meg Ohm $\frac{1}{2}$ W 10%
09-5161-0	100 Ohm $\frac{1}{2}$ W 10%
09-5164-0	820 Ohm $\frac{1}{2}$ W 10%
09-5166-0	47 K Ohm $\frac{1}{2}$ W 10%
09-5170-0	470 K Ohm $\frac{1}{2}$ W 10%
09-5278-0	10 K Ohm $\frac{1}{2}$ W 10%
09-5279-0	12 K Ohm $\frac{1}{2}$ W 10%
09-5281-0	68 K Ohm $\frac{1}{2}$ W 10%
09-5363-0	56 K Ohm $\frac{1}{2}$ W 10%
09-5461-0	47 Ohm $\frac{1}{2}$ W 10%
09-5462-0	470 Ohm 5W 5%
09-5463-0	750 Ohm 5W 5%
09-5464-0	1 K Ohm $\frac{1}{2}$ W 10%
09-5465-0	4.7 K Ohm $\frac{1}{2}$ W 10%
09-5466-0	33 K Ohm $\frac{1}{2}$ W 10%
09-5467-0	100 K Ohm $\frac{1}{2}$ W 1%
09-5182-0	500 K Ohm Pot. Volume
09-5370-0	1 Meg Ohm Pot. (Bass & Treble)
09-5472-0	25 K Ohm Pot. (Bias Adj.)